

## Standoff Information

Standoffs are spacers that include threads. Common uses include:

- Connecting or extending parts
- Separating two parts from one another (e.g., circuit board from chassis)
- Providing minimum clearance in limited-space applications
- Locating and guiding parts in assemblies

### STANDOFF TYPES

#### Hex

Easy to grip with a wrench or pliers, so they are used primarily where holding and tightening with a tool is required. Common uses include:

- Mating cables between two pieces of like hardware
- Mounting D-type electronic connectors to a computer panel

#### Round

General-use threaded spacers are excellent for applications requiring close control of dimensions. Common uses include:

- Attaching and spacing printed circuit boards and subassemblies
- Preventing crushing of lightweight structural materials at fastening points