

SmartKey™ Lock Rekeying Guide



Easy-to-use tool allows lock to be rekeyed without removing lock from door.

TO REKEY LOCK:



1) Insert functioning key into lock and turn key 1/4 turn clockwise.



2) Insert and remove SmartKey™ learn tool. Remove the current key.



3) Insert new key into lock and turn key 1/2 turn counterclockwise. Lock is now rekeyed.