

## How to Select Power Attic Ventilators

For proper attic ventilation, the Home Ventilation Institute recommends a system that provides at least 10 air exchanges an hour. Use the following formula to determine the fan capacity (cubic

feet per minute, CFM) needed to provide this minimum airflow.

$$\text{Attic Square Feet} \times 0.7 = \text{CFM}$$

Note: For roofs pitched 7/12 or higher, you may want to add 20% more CFM capacity to handle the larger volume of attic space; 30% more for roofs 11/12 and higher.